

ELECTRICAL SYSTEM DIAGRAM LEGEND

1) Horn

2) Aerial

3) Right switch

4) Ignition relay

5) Fuse box

6) Code control unit

7) Ignition key unit

8) Starter motor

9) Solenoid starter

10) Battery

11) Instrument water temperature

sensor

12) Fan

13) Rear right-turn indicator

14) Tail light

15) Number plate lighting bulb

16) Left-turn indicator

17) Power outlet

18) Tank

19) Diagnosis connector

20) Horizontal cylinder spark plug

21) Vertical cylinder spark plug

22) Horizontal cylinder injector

23) Vertical cylinder injector

24) Throttle position sensor

25) Timing/rpm pick-up

26) Control unit coolant temperature

sensor

27) 5.9 control unit

28) Regulator fuse

29) Regulator

301 Generator

31) Stand sensor

32) Neutral light switch

33) Oil pressure switch

34) Rear stop light switch

35) Front stop light switch

36) Turn indicator flasher

37) Left switch

38) Instrument panel

39) Lamps relay

40) Front left-turn indicator

41) Headlight

42) Front right-tum indicator

43) Injection relay

Wire color coding

Bk Black

Bn Brown

G Green

Gr Grey

Lb Light blue

P Pink

R Red

V Violet

Y Yellow

Y-G Yellow-Green

R-Bk Red-Black

Y-Bk Yellow-Black

O-Bk Orange-Black

G-W Green-White

Gr-R Grey-Red

V-Bk Violet-Black

W-R White-Red

G-B Green-Blue

G-Bk Green-Black

Gr-Bk Grey-Black

R-G Red-Green

W-B White-Blue

O-W Orange-White

R-B Red-Blue

Legend of fuse box		
Pos.	Description	Rat.
1-9	Main switch	30 A
2-10	Lamps relay	20 A
3-11	Stop light, horn, transducer	20 A
4-12	Control unit power supply	3 A
5-13	Key-sense	7.5 A
6-14	Injection	20 A
7-15	Display	3 A
8-16	Power outlet	3 A